

NOTES:

1. Observe proper polarity when using voltage or current devices.
2. If airflow and high limit switches are not used, a jumper must be installed.

————— By Carnes
- - - - - By Others

